

ASSEMBLY INSTRUCTIONS

1. Attach Post Support (#4) to Base (#1).
 2. Insert Post (#2) into the Post Support (#4). Secure by aligning the holes of both the Post (#2) and Post Support (#4) and inserting (1) 5/8" x 2-1/2" Clevis Pin (#5), (2) 11/16" Washers (#6) and (1) Cotter Pin (#7).
- See exploded diagram for proper placement.

ITEM NO.	PART NO.	DESCRIPTION	QTY.
1	6809A01	Base	1
2	6809A02	Post	1
3	6809A03	Handle Grip	2
4	6809A04	Post Support	1
5	6809A05	5/8" x 2-1/2" Clevis Pin	1
6	6809A06	11/16" Washer	2
7	6809A07	Cotter Pin	7
8	6809A08	Handle Assembly w/Grips	1
9	6809A09	Acme Rod	1
10	6808BD02	Bearing Assembly	1

