


PARTS BREAKDOWN

6-720



REF. NO.	PART NO.	DESCRIPTION	QTY.
1	RS72001	Motor Housing	1
2	RS72002	Anvil	1
3	RS72003	Socket Retaining Ring	1
4	RS72004	Throttle Lever	1
6	RS72006	Anvil Bushing	1
7	RS72007	Hammer	1
8	RS72008	Hammer Cage	1
10	RS72010	Hammer Pin	1
11	RS72011	Cam	1
12	RS72012	Oil Screw	1
13	RS21114	Ball Bearing	1
14	RS72014	Rear End Plate	1
15	RS72015	Rotor	1
16	RS72016	Rotor Blade	6
17	RS72017	Throttle Pin	2
18	RS72018	Cylinder	1
19	RS72019	Front End Plate	1
20	RS72131	Ball Bearing	1
21	RS72021	Back Cap	1
22	RS72022	O-Ring	2
23	RS72023	Back Cap Gasket	1
24	RS72024	Motor Pin	1
25	RS72025	Plunger	2

REF. NO.	PART NO.	DESCRIPTION	QTY.
26	RS72026	O-Ring	1
27	RS72027	Valve	2
28	RS72028	Snap Ring	1
29	RS72029	Retainer Ring	1
30	RS72030	O-Ring	2
31	RS72031	Air Inlet Block	1
32	RS72032	Regulator	1
33	RS72033	O-Ring	1
34	RS72034	O-Ring	1
35	RS72035	Screw	2
36	RS72036	Oil Seal	1
37	RS72037	Retainer Plate	1
38	RS72038	Oil Seal	1
39	RS72039	Rubber Nose Guard	1
40	RS72040	Plunger Spring	2
41	RS72041	Valve Seat	2
42	RS72042	Valve Spring	2
43	RS72043	Short Cap Screw	2
44	RS72044	Long Cap Screw	2
45	RS72045	Steel Ball	1
46	RS72046	Spring	1
49	RS72049	Snap Ring	1

PLEASE REVIEW ALL WARNING INSTRUCTIONS PRIOR TO OPERATION. SAVE THIS MANUAL FOR FUTURE REFERENCE.