


PARTS BREAKDOWN

6-747



PARTS LIST

6-747

REF. NO.	PART NO.	DESCRIPTION	QTY.
1	700402	Motor Housing	1
2	700308	O-Ring	1
3	700309	Oil Plug	1
4	700307	Throttle Trigger	1
5	700306	Stop Cover	1
6	700305	Stop Cover Gasket	1
7	700403	O-Ring	1
8	700373	Throttle Bushing	1
9	700303	O-Ring	1
10	700360	O-Ring	1
11	700363	Throttle Pin	1
12	700077	Screw	2
13	700361	Valve Stem	1
14	700362	Valve Spring	1
15	700063	Exhaust Deflector	1
16	700064	Hose Adaptor	1
17	700411	Gasket	1
18	700410	End Cap	1
19	700072	O-Ring	1
20	700311A	Air Regulator Reverse	1
21	700312	Spring	1
22	700474 OK	Stop Pin	1
23	700074	CE Ring	1
24	729478	Ball Bearing	2
25	700409	Rear Plate	1
26	700408	Rotor	1
27	729913A	Rotor Blade	6
28	700407	Cylinder	1
29	730032	Guide Pin	1
30	729477	Oil Seal	1
31	730036	O-Ring	1
32	700406	Front Plate	1
33	729462A	Screw w/Washer	8
34	700413	Hammer Cage	1
35	700414	Hammer	2
36	700415	Hammer Pin	2
37	700416	Anvil (optional)	1
38	700417	Anvil Spacer	1
39	1008695	O-Ring	1
40	1013129	Socket Ring	1
41	700432B	Black Steel Housing	1
42	700419	Anvil Bushing	1
43	1012961	Oil Seal	1
44	1011084	O-Ring	1
45	700420	2" Ext. Anvil	1

PLEASE REVIEW ALL WARNING INSTRUCTIONS PRIOR TO OPERATION. SAVE THIS MANUAL FOR FUTURE REFERENCE.