



**PARTS LIST**

6-757

REF. NO.	PART NO.	DESCRIPTION	QTY.
1	380101	Motor Housing	1
2	233A02	Lever Pin	1
3	233A03	Air Inlet	1
4	380104	Throttle Lever	1
5	233A05	Valve Stem	1
6	233A06	Exhaust Deflector	1
7	233A07	O-Ring	1
8	233A08	Valve Spring	1
9	233A09	O-Ring	1
10	233A10	Throttle Valve Plug	1
11	233A11	O-Ring	1
12	233A12	Rotor Bush	1
13	21114	Ball Bearing	1
14	233A14	Rear End Plate	1
15	233A15	Rotor	1
16	233A16	Rotor Blades	4
17	233A17	Pin	3
18	380118	Cylinder	1
19	233A19	Front End Plate	1
20	10920	Ball Bearing	1
21	233A21	Air Regulator	1
22	230B22	Spindle	1
23	230B23	Retainer	1
24	230B24	Collet	1
25	230B25	Collet Nut	1
26	230B26	Housing Cap	1
27	230B27	Angle Double Ended Spanner	1
28	233A28	Double Ended Spanner	1
29	233A29	Retainer Ring	1
32	380132	Spring	1
33	380133	Safety Bar	1
34	380134	Spring Pin	1