



PARTS LIST

6-772

REF. NO.	PART NO.	DESCRIPTION	QTY.
1	67001	Housing	1
2	67002	Valve Sleeve	1
3	67003	Reverse Valve	1
4	67004	Trigger	1
5	67005	Pin	1
6	67006	Screw	1
7	67007	Valve Stem	1
8	67008	Valve Ball	1
9	67009	Spring	1
10	67010	Hose Adapter	1
11	67011	Screen	1
12	67012	Air Regulator	1
13	67013	O-Ring	1
14	67014	Pin	1
15	67015	Oil Seal	1
16	67016	Spacer	1
17	67017	Anvil Bushing	1
18	67018	Anvil	1
19	67019	Hammer Cage	1
20	67020	Hammer Bar	2
21	67021	Driver Cam Foundation	1
22	67022	Drive Cam	1
23	67023	O-Ring	1
24	67024	Cylinder	1
25	67025	Rotor	1
26	67026	Rotor Blade	6
27	67027	Front End Plate	1
28	221RA32	Ball Bearing	1
29	67029	Rear End Plate	1
30	77128	Ball Bearing	1
31	67031	Spring	1
32	67032	Pin	1
33	67033	Rear Gasket	1
34	67034	Rear Cover	1
35	67035	Washer	4
36	67036	Screw	4
37	67037	Washer	3
38	67038	Screw	3
39	67039	Exhaust Deflector	1
40	67040	Screw	2
41	67041	Screw	1
42	67042	Anvil Collar	1
43	67043	O-Ring	1
44	67044	Protecting Rubber	1
45	67045	Screw	1
46	67046	Spring	1
47	67047	Steel Ball	1
48	67048	Muffler	1
49	67049	Oil Seal	1
50	67050	Protecting Rubber	1

Comes →
w/Asg.
26
11-8-04

Not in
tool.
26
11-8-04