


# SX860



Ref. #	Item #	DESCRIPTION	QTY
1	RS8601	Motor Housing Assembly	1
2A	RS8602A	Throttle Valve Seat	1
3A	RS8603A	Throttle Valve	1
4	RS76904	Hammer Case Cap Screw	4
5	RS76905	Lock Washer	8
6	RS8606	Hammer Case	1
7	RS8607	Hammer Case Gasket	1
9	RS21109	Bearing	2
10	RS8610	End Plate Gasket	1
11	RS8611	End Plate	2
12	RS76912	Pin	2
13	RS76913	Rotor Blade	6
14	RS8614	Rotor	1
15	RS8615	Cylinder	1
16	RS8616	Trigger	1
17A	RS8617A	Valve Pin	1
18	RS76918	Hammer Frame Rear Washer	1
20	RS8620	Reverse Valve	1
20A	RS8620A	O-Ring	1
21	RS8621	O-Ring	1
22	RS8622	O-Ring	1
23	RS8623	Back Cap Gasket	1
24	RS8624	Back Cap	1
25	RS8625	Air Regulator	1
26	RS8626	Spring	1
27	RS8627	Steel Ball	1
28	RS8628	Throttle Valve Spring	1

Ref. #	Item #	DESCRIPTION	QTY
29	RS8629	Exhaust Deflector	1
30	RS8630	Air Inlet	1
31	RS76931	Hammer Frame	1
32	RS76932	Hammer	2
33	RS76933	Hammer Pin	2
34	<del>RS16234</del>	Standard Anvil (Including #35 & #36)	1
35	RS85311	O-Ring	1
36	RS76936	Socket Retainer	1
37	RS76937	Hammer Case Bushing	1
39	RS76939	Screw	4
40	RS76940	Oil Seal	1
41	RS76941	Screw	2
42	RS8642	End Cap	1
43	RS8643	Muffler Element	1